


## HWHC44-370GCE to HWHC63-370GCE Replacement Parts List

Nr.	Description item	Item Comments	Gas	Refer To Drawing On Page 2	
				HWHC44-370GCE	HWHC63-370GCE
1	Controller	Control Kit HWHC/HWH			LV311399
2	Gas valve	Gas Valve/Venturi Assembly	G20		LV310155
		Gas Valve/Venturi Assembly	G31		LV310157
3	Burner Assembly	Burner Assembly	All		LV309297
4	Power Anode / Ti-anode / Ti-electrode	Anode Short 305mm			LV197709
5		Anode Long 1220mm			LV197710
6	Fan	Fan RG148/1200-3633			LV309159
7	Hot Surface Igniter	Hot Surface Igniter Service Kit			LV309232
8	Flame Sense Electrode	Flame Sensor			LV310075
9	Correx Potentiostat	Correx Potentiostat 2.3			LV306160
10	Temperature Sensor	Sensor Top Of Vessel (4 pins)			LV304469
11	Temperature Sensor	Sensor Bottom Of Vessel (2 pins)			LV308149
12	Air Proving Switch Assembly	Air Proving Switch Assembly (115 Pa)			LV309169
13	Cable Assembly	Cable Assembly			LV309136
14	Gasket And Fixings Kit	Gasket/Mounting Set			LV309608
15	Air Inlet Pipe	Air Inlet Connection Pipe			LV309148
16	Inspection Door Service Kit	Inspection Door Service Kit			LV305082
17	Drain Valve	Drain Valve 1"			LV308997
18	Flue Transition Collar	Connector Exhaust			LV192636
19	Solar Control	Solar Heat Master - Lochinvar Ltd			LV311400
20	Sensor Collector	Collector Sensor Single (20k/2 pins)			LV308904
21	Temperature Sensor	Temp. Sensor Single (2 pins/short)			LV308149
22	LPG Governor	LPG Governor			LV310180
-	Gas Valve Cable				LV309336

**Note.** Use in

conjunction with Drawings *EVD-0056* below

# HWHC44-370GCE to HWHC63-370GCE Replacement Parts List



REVISE BY  
COMPUTER  
ONLY

**A3**  
SIZE



Lochinvar  
HIGH EFFICIENCY BOILERS & WATER HEATERS

ECOCHARGER HYBRID  
HWHC 44-370 / 63-370

DRAWING  
NUMBER **EVD-0056**

REV.	RELEASE	CHANGES	CHG.NO.	BY	DATE	CH
0	RELEASE		8964	MS	060614	