


ECOFORCE™ SPARE PARTS LIST

For use on water heater serial numbers starting E65.014.2** ONLY


EF80-120



ECOFORCE™ SPARE PARTS LIST

For use on water heater serial numbers starting E65.014.2** ONLY

EF80-120



ECOFORCE™ SPARE PARTS LIST

For use on water heater serial numbers starting E65.014.2** ONLY

Item No	Description of item	Item Comments	EF80	EF100	EF120
1	LH SIDE PANEL			LE01000298	
2	IGNITION CABLE			LE04016583	
3	ELECTRODE SET			LE04000372	
4	COMBUSTION CHAMBER REAR WALL INSULATION			LE04000213	
5	BURNER DOOR INSULATION			LE07010093	
6	BURNER DOOR			LE04000056	
7	GAS VALVE			LE04000188	LE04000237
8	GAS VALVE O RING	EF120 requires extra o rings and gaskets		LE07002018	LEO7002018 LEO7000237 E07001101
9	RH SIDE PANEL			LE01000299	
10	GAS AIR MIXING BOX			LE05000087	
11	COMBUSTION FAN			LE04000069	
12	COMBUSTION PIPE GASKET			LE07001049	
13	SET ROUND HEAD SCREWS X5			LE06023002	
14	FRONT PANEL INSULATION			LE01000319	
15	GAS/AIR INLET PIPE			LE03000160	
16	BURNER GASKET			LE07001029	
17	BURNER			LE04012025	
18	SET NUTS WITH FLANGE			LE06023001	
19	BURNER DOOR THERMOSTAT			LE04016667	
20	BURNER DOOR OUTER SEAL			LE07004035	
21	INLET PIPE KIT		LE02000107	LE02000109	
22	CONDENSATE HOSE			LE04007110	
23	MOUNTING BRACKET			LE01001014	
24	BRACKET		LE01000287	LE01000288	
25	AIR PRESSURE SWITCH			LE04000305	

ECOFORCE™ SPARE PARTS LIST


For use on water heater serial numbers starting E65.014.2** ONLY

Item No	Description of item	Item Comments	EF80	EF100	EF120
26	CONDENSATE DRAIN CONNECTION			LE05000135	
27	CONDENSATE WATER TRAP			LE05000115	
28	CONDENSATE DRAIN HOSE			LE04007038	
29	230V NET CABLE			LE04016142	
30	PG9 SWIVEL AND CABLE GLAND			LE05000064	
31	18-5MM GROMETT			LE04010031	
32	5A FUSE			LE04016582	
33	BURNER CONTROL			LE1001EN014	
34	DISPLAY PCB			LE04000224	
35	RUBBER PLUG			LE05001062	
36	CONNECTOR STRIP COVER			LE01000317	
37	HEAT EXCHANGER		LE04000285	LE04000286	LE04000287
38	FLUE GAS TEMPERATURE SENSOR			LE04016621	
39	HIGH LIMIT THERMOSTAT			LE04016066	
40	FLOW/RETURN TEMP- SENSOR			LE04016287	
41	HEAT EXCHANGER OUTLET SEAL		LE07004030	LE07004031	
42	HIGH PRESSURE WATER SWITCH			LE04015081	
43	OUTLET PIPE KIT		LE02000112	LE02000110	
44	HEAT EXCHANGER PIPE CLIP		LE09002021	LE09002022	
45	HEAT EXCHANGER INLET O RINGS		LE07002032	LE07002033	
46	AUTOMATIC AIR VENT			LE04015073	

ECOFORCE™ SPARE PARTS LIST

For use on water heater serial numbers starting E65.014.2** ONLY


EF150-180



ECOFORCE™ SPARE PARTS LIST

For use on water heater serial numbers starting E65.014.2** ONLY

EF150-180



ECOFORCE™ SPARE PARTS LIST

For use on water heater serial numbers starting E65.014.2** ONLY

Item No	Description of item	Item Comments	EF150	EF180
1	LH SIDE PANEL			LE01000315
2	IGNITION CABLE			LE04016583
3	ELECTRODE SET			LEO4000372
4	COMBUSTION CHAMBER REAR WALL INSULATION			LE04000213
5	BURNER DOOR INSULATION			LE07010093
6	BURNER DOOR			LE04000056
7	GAS VALVE			LE04000190
8	GAS VALVE O RING			LE07002018
9	RH SIDE PANEL			LE01000316
10	GAS AIR MIXING BOX			LE05000090
11	COMBUSTION FAN			LE04000070
12	COMBUSTION PIPE GASKET			LE07001039
13	SET ROUND HEAD SCREWS X5			LE06023002
14	FRONT PANEL INSULATION			LE01000320
15	GAS/AIR INLET PIPE			LE03000161
16	BURNER GASKET			LE07001029
17	BURNER		LE04012028	LE04012029
18	SET NUTS WITH FLANGE			LE06023001
19	BURNER DOOR THERMOSTAT			LE04016667
20	BURNER DOOR OUTER SEAL			LE07004035
21	INLET PIPE KIT			LE02000111
22	CONDENSATE HOSE			LE04007110
23	MOUNTING BRACKET			LE01001014
24	BRACKET			LE01000288
25	AIR PRESSURE SWITCH			LE04000305

ECOFORCE™ SPARE PARTS LIST

For use on water heater serial numbers starting E65.014.2** ONLY

Item No	Description of item	Item Comments	EF150	EF180
26	CONDENSATE DRAIN CONNECTION			LE05000135
27	CONDENSATE WATER TRAP			LE05000115
28	CONDENSATE DRAIN HOSE			LE04007038
29	230V NET CABLE			LE04016142
30	PG9 SWIVEL AND CABLE GLAND			LE05000064
31	18-5MM GROMETT			LE04010031
32	5A FUSE			LE04016582
33	BURNER CONTROL			LE1002EN014
34	DISPLAY PCB			LE04000224
35	RUBBER PLUG			LE05001062
36	CONNECTOR STRIP COVER			LE01000317
37	HEAT EXCHANGER		LE04000288	LE04000289
38	FLUE GAS TEMPERATURE SENSOR			LE04016621
39	HIGH LIMIT THERMOSTAT			LE04016066
40	FLOW/RETURN TEMP- SENSOR			LE04016287
41	HEAT EXCHANGER OUTLET SEAL			LE07004025
42	HIGH PRESSURE WATER SWITCH			LE04015081
43	OUTLET PIPE KIT			LE02000114
44	HEAT EXCHANGER PIPE CLIP			LE09002023
45	HEAT EXCHANGER INLET O RINGS			LE07002034
46	AUTOMATIC AIR VENT			LE04015073