



Spares Parts List

SIVT66 - 220GE after 1-6-2017

Nr.	Description of Item	Item Comments	Refer To Drawing						
			page 2	page 3					
			SIVT66	SIVT100	SIVT110	SIVT130	SIVT165	SIVT220	
1	Anode	Anode ITS (L)	LV312657	-					
		Anode Magnesium 970mm 1¼"	-	LV301639		-			
		Anode Magnesium 1360mm 1¼"	-		LV301641				
	Flexible Anode	Anode Magnesium Flex 1¼"	-		LV301727				
2	Gasket Clean Out	Gasket Clean Out (L)	LV312658	-					
		Gasket Flange	-	LV301535		LV301536			
3	Immersion Well Set	Immersion Well	LV312790	-					
6	Clean out door Cover Front	Cover Front	LV312661	LV312812		LV312816			
7	Top Cover Jacket	Cover Jacket	LV312662	LV312779					LV312811
8	Complete linsulation Package (Insulation Jacket, Insulation Top and Cover Jacket)	Insulation I2-300 ALU (L)	LV312654	-					
		Insulation I2-400 ALU	-	LV312714	-				
		Insulation I2-500 ALU	-		LV312715	-			
		Insulation I2-600 ALU	-			LV312716	-	-	
		Insulation I2-750 ALU	-				LV312717	-	
		Insulation I2-1000 ALU	-					LV312718	
9	Flange Clean Out	Clean Out Flange (L)	LV312659	-					
		Flange	-	LV301517		-			
			-			LV301534			





LINEAR TOLERANCES UNLESS NOTED DECIMALS ± 0.1mm / ANGLES ± 0.2°		REVERSE BY COMPUTER ONLY		AM PROJ.		---		Designed with 		 Lochinvar [®] High Efficiency Water Heaters and Boilers		
SIDE TOLERANCES SHAVE AND PLACE TOLERANCES		SEE NENISO 400 SEE NENISO 1101				SCALE						
											A4 SIZE	
											SIVT 100-220	
MATERIAL		-										
FINISH SPEC.		-										
												PART NUMBER EVD-0081
D	RELEASE											