

Charger PP Spare Parts List (GCE & PGCE Models)

No	Description item	Item Comment	CH100	CH155	CH200	CH300	CH400	CH500	CH600
1	Flue Baffle		LV068440002						
2	Sealant U-profile		LV305098						
3	Anode	Magnesium (991 mm)	LV183463039			-	-	LV183463039	
		Magnesium (1270 mm)	-	-	-	LV183463050		-	-
	Flexible Anode	Magnesium Flexible (1126 mm)	LV304728						
4	Thermostat Roll-Out (TRS)	105°C	LV306344				-	-	-
		110°C	-	-	-	-	LV306345	-	-
		115°C	-	-	-	-	-	LV306346	
5	Connection Cable		LV305346						
6	O-ring Clean Out		LV304741						
7	Inspection Door Service Kit	Clean Out Door Service Kit	LV301125						
8	Piezo Assembly		LV307596						
9	Control Thermostat	40-73°C	LV302989						
9A	ON/OFF Switch		LV303011						
10	High Limit Thermostat	84°C	LV302991						
11	Overheat Thermostat	93°C	LV300674						
12	Gas Valve	Natural Gas	LV070115						
		LPG	LV070115002						
13	Ignition Burner		LV304892						
14	Standard Burner		LV304891						
15	Pilot Burner Assembly	Natural Gas	LV301104						
	Complete Set of Pilot Burner, Pilot Tube, Thermocouple and Ignition Cable	LPG	LV301105						
16	Gas Isolation Valve	3/4"	LV300719						
POWER ANODE SPARE PARTS - These spare parts are for units that are factory fitted with power anodes									
17	Correx Power Anode	300 mm	LV307448						
18	Correx Cable Double Anode		LV310544						
19	CORREX Box		LV310539						
20	Correx Cable Control		LV310541						

Note. Use in conjunction with Drawings EVD0032 below

