


ECOFORCE™ SPARE PARTS LIST

For use on water heater serial numbers starting E65.014.2** ONLY


EF80-120



ECOFORCE™ SPARE PARTS LIST

For use on water heater serial numbers starting E65.014.2** ONLY

EF80-120



ECOFORCE™ SPARE PARTS LIST

For use on water heater serial numbers starting E65.014.2** ONLY

Item No	Description of item	Item Comments	EF80	EF100	EF120
1	LH SIDE PANEL			LE01000298	
2	IGNITION CABLE			LE04016583	
3	ELECTRODE SET			LE04000372	
4	COMBUSTION CHAMBER REAR WALL INSULATION			LE04000213	
5	BURNER DOOR INSULATION			LE07010093	
6	BURNER DOOR			LE04000056	
7	GAS VALVE			LE04000188	
8	GAS VALVE O RING	INCLUDED WITH GAS VALVE FOR EF120		LE07002018	
9	RH SIDE PANEL			LE01000299	
10	GAS AIR MIXING BOX			LE05000087	
11	COMBUSTION FAN			LE04000069	
12	COMBUSTION PIPE GASKET			LE07001049	
13	SET ROUND HEAD SCREWS X5			LE06023002	
14	FRONT PANEL INSULATION			LE01000319	
15	GAS/AIR INLET PIPE			LE03000160	
16	BURNER GASKET			LE07001029	
17	BURNER			LE04012025	
18	SET NUTS WITH FLANGE			LE06023001	
19	BURNER DOOR THERMOSTAT			LE04016667	
20	BURNER DOOR OUTER SEAL			LE07004035	
21	INLET PIPE KIT		LE02000330	LE02000109	
22	CONDENSATE HOSE			LE04007110	
23	MOUNTING BRACKET			LE01001014	
24	BRACKET		LE01000287	LE01000288	
25	AIR PRESSURE SWITCH			LE04000305	

ECOFORCE™ SPARE PARTS LIST


For use on water heater serial numbers starting E65.014.2** ONLY

Item No	Description of item	Item Comments	EF80	EF100	EF120
26	CONDENSATE DRAIN CONNECTION		LE05000135		
27	CONDENSATE WATER TRAP		LE05000115		
28	CONDENSATE DRAIN HOSE		LE04007038		
29	230V NET CABLE		LE04016142		
30	PG9 SWIVEL AND CABLE GLAND		LE05000064		
31	18-5MM GROMETT		LE04010031		
32	5A FUSE		LE04016582		
33	BURNER CONTROL		LE1001EN014		
34	DISPLAY PCB		LE04000224		
35	RUBBER PLUG		LE05001062		
36	CONNECTOR STRIP COVER		LE01000317		
37	HEAT EXCHANGER		LE04000285	LE04000286	LE04000287
38	FLUE GAS TEMPERATURE SENSOR		LE04016621		
39	HIGH LIMIT THERMOSTAT		LE04016066		
40	FLOW/RETURN TEMP- SENSOR		LE04016287		
41	HEAT EXCHANGER OUTLET SEAL		LE07004030	LE07004031	
42	HIGH PRESSURE WATER SWITCH		LE04015081		
43	OUTLET PIPE KIT		LE02000329	LE02000110	
44	HEAT EXCHANGER PIPE CLIP		LE09002021	LE09002022	
45	HEAT EXCHANGER INLET O RINGS		LE07002032	LE07002033	
46	AUTOMATIC AIR VENT		LE04015073		

ECOFORCE™ SPARE PARTS LIST

For use on water heater serial numbers starting E65.014.2** ONLY


EF150-180



ECOFORCE™ SPARE PARTS LIST

For use on water heater serial numbers starting E65.014.2** ONLY

EF150-180



ECOFORCE™ SPARE PARTS LIST

For use on water heater serial numbers starting E65.014.2** ONLY

Item No	Description of item	Item Comments	EF150	EF180
1	LH SIDE PANEL		LE01000315	
2	IGNITION CABLE		LE04016583	
3	ELECTRODE SET		LEO4000372	
4	COMBUSTION CHAMBER REAR WALL INSULATION		LE04000213	
5	BURNER DOOR INSULATION		LE07010093	
6	BURNER DOOR		LE04000056	
7	GAS VALVE		LE04000190	
8	GAS VALVE O RING		LE07002018	
9	RH SIDE PANEL		LE01000316	
10	GAS AIR MIXING BOX		LE05000090	
11	COMBUSTION FAN		LE04000070	
12	COMBUSTION PIPE GASKET		LEO7001039	
13	SET ROUND HEAD SCREWS X5		LE06023002	
14	FRONT PANEL INSULATION		LE01000320	
15	GAS/AIR INLET PIPE		LE03000161	
16	BURNER GASKET		LE07001029	
17	BURNER	For EF180 Do not order without referring to product bulletin 19 02	LE04012028	LE04012043
18	SET NUTS WITH FLANGE		LE06023001	
19	BURNER DOOR THERMOSTAT		LE04016667	
20	BURNER DOOR OUTER SEAL		LE07004035	
21	INLET PIPE KIT		LE02000111	
22	CONDENSATE HOSE		LE04007110	
23	MOUNTING BRACKET		LE01001014	
24	BRACKET		LE01000288	
25	AIR PRESSURE SWITCH		LE04000305	

ECOFORCE™ SPARE PARTS LIST

For use on water heater serial numbers starting E65.014.2** ONLY

Item No	Description of item	Item Comments	EF150	EF180
26	CONDENSATE DRAIN CONNECTION		LE05000135	
27	CONDENSATE WATER TRAP		LE05000115	
28	CONDENSATE DRAIN HOSE		LE04007038	
29	230V NET CABLE		LE04016142	
30	PG9 SWIVEL AND CABLE GLAND		LE05000064	
31	18-5MM GROMETT		LE04010031	
32	5A FUSE		LE04016582	
33	BURNER CONTROL		LE1002EN014	
34	DISPLAY PCB		LE04000224	
35	RUBBER PLUG		LE05001062	
36	CONNECTOR STRIP COVER		LE01000317	
37	HEAT EXCHANGER		LE04000288	LE04000289
38	FLUE GAS TEMPERATURE SENSOR		LE04016621	
39	HIGH LIMIT THERMOSTAT		LE04016066	
40	FLOW/RETURN TEMP- SENSOR		LE04016287	
41	HEAT EXCHANGER OUTLET SEAL		LE07004025	
42	HIGH PRESSURE WATER SWITCH		LE04015081	
43	OUTLET PIPE KIT		LE02000114	
44	HEAT EXCHANGER PIPE CLIP		LE09002023	
45	HEAT EXCHANGER INLET O RINGS		LE07002034	
46	AUTOMATIC AIR VENT		LE04015073	