


Spares Parts List

SIVT66 - 220GE pre 31-5-2017

Nr.	Description of Item	Item Comments	Refer To Drawing				
			page 2				
			SIVT100	SIVT110	SIVT130	SIVT165	SIVT220
1	Anode	Anode ITS (L)	-				
		Anode Magnesium 970mm 1¼"	LV301639		-		
		Anode Magnesium 1360mm 1¼"	-		LV301641		
	Flexible Anode	Anode Magnesium Flex 1¼"	-	LV301727			
2	Gasket Clean Out	Gasket Clean Out (L)	-				
		Gasket Flange	LV301535		-		
			-		LV301536		
3	Immersion Well	Immersion Well 120mm (L)	-				
4		Immersion Well 55mm (L)	-				
5	Levelling Screw	Levelling Screw (M10x50)	-				
6	Cover Front	Cover Front	LV301507		-		
			-		LV301509		
7	Cover Jacket (Cover Jacket with Insulation)	Cover Jacket	LV304504		-	-	-
			-		LV304505		-
			-				
8	Complete linsulation Package (Insulation Jacket, Insulation Top and Cover Jacket)	Insulation I2-300 ALU (L)	-				
		Insulation I2-400 ALU	LV302858	-			
		Insulation I2-500 ALU	-	LV302862	-		
		Insulation I2-600 ALU	-		LV302866	-	-
		Insulation I2-750 ALU	-			LV302870	-
		Insulation I2-1000 ALU	-				LV302874
9	Flange Clean Out	Clean Out Flange (L)	-				
		Flange	LV301517		-		



LINEAR TOLERANCES UNLESS NOTED
DECIMALS ± .01mm / ANGLES ± 2°

REVERSE BY
COMPUTER ONLY

AM PROJ.

SCALE

Designed with
SolidWorks

SIZE
A4

SIVT 100-220

MATERIAL
-

FINISH SPEC.
-

LOCHINVAR®
High Efficiency Water Heaters and Boilers

PART
NUMBER
EVD-0081

SIDE TOLERANCES
SHAVE AND PLACE TOLERANCES DEC. NENISO 1101

0 RELEASE

CHANGES

8859 MS 220114

CH